

Paint Repair & Maintenance





FluoroGrip® is used as a repair and maintenance system designed to extend the life of traditional coating systems by repairing damaged and rusted areas while they are small.

Integument

Integument Technologies, Inc.
70 Pearce Avenue, Tonawanda, NY 14150
Phone: (716) 873-1199 • Fax: (716) 873-1303
e-mail: info@integument.com
www.integument.com



Shipboard Testing - Ballast Tanks (Pressure & Vacuum)





Application / Adhesion Test

- Main Ballast tanks on a US Navy nuclear submarine
 - Immersion Service 20 test patches


Set A Applied Successfully

- Over <u>new epoxy</u>, <u>aged intact epoxy</u>, <u>bare metal</u> prepared by needle gunning
- Around beam edges / angles

Results

- Test patches still exhibit sound adhesion.
- Evaluation in July 2001: Removal & recoat Edge sealant
- August 2002 inspection & evaluation no apparent change
- Evaluation in January 2003: Test patches w duration of 11 months, 18 months, and 29 months – All in sound condition

Peel Strength, 180° ASTM D 903-98



Test Method

- Adhere test strips to a painted panel, then exert a measured force 180° to the surface to pull off the strips
- Set A applied over three different surface preparations (cured AC, tacky AC, sanded AC)

Conclusions

- No apparent differences in adhesion between surface preparations
- Films show <u>excellent adhesion</u> Strips elongate prior to adhesive failure

Std Dev (Lb/in)
0.2
0.3
0.3

Salt Spray (Fog) Testing ASTM B 117-85



Purpose: Evaluate Adhesion of Appliqué over Anticorrosive Paint, & in Overlap & Edge Situations

- Accelerated test 2000 hours
- Set A applied over three different surface preparations (cured AC, tacky AC, sanded AC)

Conclusions

- No apparent differences between surface preparations
- Applique shows slight lifting at scribe due to exposed edge
- Real-time testing underway

ASTM Rust D 610 Blisters D 714 Dry 10 10 Tacky 10 10 Sanded 10 10 Control 10 10

Integument

Integument Technologies, Inc.

70 Pearce Avenue, Tonawanda, NY 14150 Phone: (716) 873-1199 • Fax: (716) 873-1303 e-mail: info@integument.com